




TIMBERLINE

ASSEMBLY GUIDE








IMPORTANT: RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.

TRAEGER PELLET GRILLS LLC
1215 E. WILMINGTON AVE., SUITE 200
SALT LAKE CITY, UT 84106

T07087

TRAEGER.COM









A good friend
and a six pack
of your favorite
beverage should
get the job done!



PLEASE READ THIS ASSEMBLY GUIDE AND YOUR OWNER'S MANUAL BEFORE INSTALLATION AND USE OF YOUR TRAEGER® GRILL. FAILURE TO FOLLOW THE INSTRUCTIONS IN THIS ASSEMBLY GUIDE AND YOUR OWNER'S MANUAL COULD RESULT IN PROPERTY DAMAGE, BODILY INJURY, OR EVEN DEATH.










Scan this code for digital/video instructions.












Scan this code for digital/video instructions.












Scan this code for digital/video instructions.






Scan this code for digital/video instructions.






Scan this code for digital/video instructions.






25

2




26



27

OPTION A


9




27

OPTION B


8



28





29






Scan this code for digital/video instructions.




Scan this code for instructions on built-in assembly.


QUICK START GUIDE




1 Press the main power button located on the front of the grill to ON.



2 Press any button to turn on the control.



3 Turn the selection dial right or left to select the temperature. Press dial, then press and hold the on-screen prompt.



4 To shut down the grill, press and hold the selection dial for 3 seconds.